



Steam Heating Coil

No Scale

Note:

1. See Valve and Fitting Installation Detail for Additional Requirements